

INSTRUCTIONS & INFORMATION



1601 INTERLOCK MODULE ADAPTER

Part Number 605937

INSTALLATION INSTRUCTIONS:

(Refer to illustration)

- Unbolt console assembly.
- Locate the 200910 safety interlock in the console wiring.
- Remove the bolt that holds the 200910 safety interlock to the console and set it aside.
- There are four (4) 18 AWG wires coming from the 200910 safety interlock that are red, yellow, black and brown along with one (1) yellow or green 14 AWG wire. The 18 AWG wires are the smaller wires.
- Now you will cut only the four (4) 18 AWG wires about 2 inches from the 200910 safety interlock. Do not cut the yellow or green 14 AWG wire.
- After the wires are cut, strip the insulation back about 3/8 of an inch.
- Locate the 605937 adapter.
- The 605937 adapter has four (4) 14 AWG wires with blue butt connectors crimped on them and one (1) green 14 AWG wire with a 5/16 inch yellow eyelet attached.
- The wires from the 200910 safety interlock that were previously cut and stripped will now be placed in the blue butt connector from the wire of the same color and crimped into the blue butt connector.
- Use the bolt from the 200910 safety interlock and bolt the 5/16 inch eyelet from the green 14 AWG wire to the hole that previously held the 200910 interlock.
- Replace the console assembly.
- Verify the safety shutdown is working properly. (See page 2)

