



INSTALLATION INSTRUCTIONS FOR DIODE WIRE 192102:

1. Locate the tractor's wiring harness in the seat cross member cutout. Cut the 2 wire ties and split the loom to locate the brown wire with a blue push - female connector on the end. This is the clutch relay wire.
2. Locate Diode Wire 192102 in kit.

