

## **INSTRUCTIONS FOR DIODE WIRE CONNECTION:**

1. Locate the tractor's wiring harness in the seat cross member cutout. Cut the 2 wire ties and split the loom to locate the brown wire with a blue push - female connector on the end. This is the clutch relay/diode wire.
2. Route diode wire to the hydraulic pump adapter harness.
3. Connect the diode wire to the unused purple wire in the adapter harness.
4. Secure wiring to stay clear of any moving parts.