

# INSTRUCTIONS & INFORMATION



## CANOPY LIGHT KIT

Part Number 503371

### LIGHTS INSTALLATION INSTRUCTIONS:

(Refer to illustration)

- Park tractor on a flat level surface.
- Disengage PTO and stop engine.
- Set park brake and remove key from ignition.
- Mount the three work lamps (item 1) to the bottom side of the canopy. Mount one at the back, centered on the canopy and facing toward the back. Mount the

other two at the front of the canopy, one to the left and one to the right, both facing toward the front. Secure each light with .312-18 x .5 whiz bolt and .312-18 whiz nut (item 2).

- Install wire assembly as shown in wiring diagram.

Item No.	Order No.	Description
1	182267	Work Lamp – LED Mini Light Bar
2	243185	Hex Bolt .312-18 x .5
	253035	Whiz Nut .312-18
3	605840	Wire Assembly – Canopy (includes items 4-9) (see wiring diagram)
4	833520	Switch Box – Canopy
5	833523	Cover – Magnetic Mount
6	102505	Magnet
7	243017	Hex Bolt .25-20 x .625
8	253440	Insert Nut .25-20
	423147	Wire Tie .125 x 5.50
9	257024	Fender Washer .250
10	162047	Decal - Canopy Lights

