

INSTRUCTIONS & INFORMATION



FOOTREST RISER

Kit Number 606378

Used on 700 & 900 front mount models.

This kit has been designed to provide a higher platform on the footrest.

INSTALLATION INSTRUCTIONS

(Refer to illustration)

- Place unit on a hard level surface.
- Disengage PTO and stop engine.
- Set park brake and remove key from ignition.
- Remove the .312 carriage bolt at the center of footrest extension that secures the footrest extension to the footrest.
- Place the Footrest Riser over the footrest so that the square hole in the front flange aligns with the square hole in the footrest extension. The back flange of the riser should rest on top of the back of the footrest.
- Reinstall the .312 carriage bolt through the square hole in the riser and through the square holes in the extension and footrest. Secure with .312 whiz nut.

