

INSTRUCTIONS & INFORMATION



95/9648 MULCHING PACKAGE

Kit Number 503591

INSTALLATION INSTRUCTIONS

(refer to illustration on page 2)

- Remove the three blades from blade spindles.
- Clean the bottom side of the mower deck removing all debris to ensure secure attachment of the front shrouds when they are installed.
- Remove the two belt shields from the top of the mower deck.
- Remove discharge shield and store; shield will be needed to convert back to a side discharge mower.
- Attach the front shrouds (items 1 & 2) to the bottom side of the deck. The front lip of each shroud fits against the inside of the mower deck's front flange. Bolt shrouds through holes in the deck and secure each with two .312-18 x .75 carriage bolt (item 6) and nuts (item 7). (Bolts will be inserted into the bottom of the deck and extend into the inside of the deck.)
- Slide the shaft of the discharge filler plate (item 3) into the pivot mount bolted inside the right side of the mower deck. Pivot the discharge filler plate counter clockwise and secure to the clevis shaft with the existing hitch pin.
- Install the three new blades (items 4 & 5) on blade spindles.
- Install the two belt shields on top of the deck.