

INSTRUCTIONS & INFORMATION



ANTI-ICING KIT - VANGUARD

Part number 503055

Used on Models 614, 616, and 718 tractors

INSTALLATION INSTRUCTIONS:

- Remove three whiz bolts from existing muffler shield and remove from engine.
- Locate the air tunnel (item 1). Slide the end with the large round hole under the back of the air cleaner with hole up and opposite end positioned over the muffler. Secure air tunnel to the bracket under the air cleaner with .187 (3/16") lock washer (item 6) and 5mm x 16mm hex bolt (item 4). The large round hole in the air tunnel should line up with a round hole in the bottom of the air cleaner.

