

INSTRUCTIONS & INFORMATION



HYDRAULIC DECK LIFT ASSEMBLY REPLACEMENT

Used when changing from mercury tilt switch to mechanical switch.

KIT NUMBER 605940

INSTALLATION INSTRUCTIONS

1. Remove existing hydraulic deck lift assembly with mercury switch and all associated wiring from tractor.
2. Mount delay timer and harness (refer to Fig.1) on the outside of the right fender mount with two .25 x .5 whiz bolts and nuts. Feed the longer purple wire and green wires through the 2" hole in frame along tractor harness down to hydraulic pump solenoid valve and connect to the valve. The yellow eyelet connecting the two green wires provides a ground connection to the right side of the engine (refer to wiring diagram). On liquid cooled models, use the same ground connection that is used by the tractor wiring. On air cooled models, use a threaded hole in the right side of the engine casting. Use part number 271020 bolt, included in kit.
3. Attach the purple wire from the hydraulic solenoid (page 2, item 1) and the shorter purple wire from delay timer (page 2, item 2) to the push button or toggle switch. Attach the black wire with fuse clip to an unused accessory fuse slot in the fuse block. Insert a 7.5 amp auto fuse into this slot.

