

# INSTRUCTIONS & INFORMATION



## ROLLER KIT – CENTER SLANT FRONT

Part Number 503625

Used on 6152, 3344, 3348 and M148 Mower Decks which do not have center roller standard.

### INSTALLATION INSTRUCTIONS:

(Refer to illustration)

- Position Roller Mount (item 1) on the center of the front plate and mark the three holes to be drilled.
- Drill three 13/32" diameter holes in mower deck.
- Install roller mount on mower deck using three 3/8-16 x 3/4" whiz bolts (item 6) and 3/8-16 whiz nuts (item 7) to secure in place. Do not tighten bolts at this time.
- Attach Center Roller Assembly (item 2) to roller mount using Roller Lock Pin (item 3). Secure pin with 5/16-18 x 3/4" whiz bolt (item 4) and 5/16-18 whiz nut (item 5).
- Adjust roller to height desired by moving roller mount up or down utilizing the slotted holes in the roller mount.
- Tighten bolts.

