

# INSTRUCTIONS & INFORMATION

## EDGER MOUNT ADAPTER KIT - M1 & 35 SERIES DECKS

Part Number 503563

Required to mount Edger to either side of rear discharge deck or trim side of all standard decks.

### INSTALLATION INSTRUCTIONS:

(Refer to illustration on page 2)

- Place unit on a flat level surface
- Disengage PTO and stop engine.
- Set park brake and remove key from ignition.
- As shown in the illustration, the Edger Mount Kit can be installed on either side of the M1 rear discharge deck and all 35 series decks.
- Attach the pivot mount (item 4) to the edger mount (item 3) and secure with two .312-18 x .75 whiz bolts and nuts (items 7 & 8).
- Position the edger mount above deck surface using two .625" spacers (item 1) between mount and deck surface. Position mount so mounting holes avoid blade shrouds located inside deck and pivot mount (item 4) avoids contact with deck. Locate the two spacers directly beneath two .343" holes in the top of edger mount.
- Temporarily clamp edger mount to the side of deck with spacers in place. Drill two .343" holes through holes in edger mount top and into deck top. Drill two .343" holes through holes in edger mount side and into deck side plate.
- Secure edger mount with two .312 x 1.25" whiz bolts and nuts (items 6 & 8) in top and two .312 x .75" whiz bolts and nuts (items 7 & 8) in side.
- Remove clamps.
- Install .312" speed nut (item 5) on angled upright on edger mount.
- Locate existing edger assembly mount, remove two .312" whiz bolts, and attach edger mount bracket (item 2) using .312 x .75" whiz bolts and nuts (items 7 & 8) as shown.
- Slide shaft of edger assembly mount into pivot mount (item 4). Rotate mount counter-clockwise and secure to edger mount with 3 prong head stud.