

INSTRUCTIONS & INFORMATION



LIGHT KIT - ENCLOSURE

Part Number 503328

Use on front mount Grasshopper models with 533405 Enclosure for 2010.5 thru 2016 model years.

INSTALLATION INSTRUCTIONS:

(refer to illustration)

- Place unit on a flat level surface.
- Disengage PTO and stop engine.
- Set park brake and remove key from ignition.
- Locate the two sets of two holes near the upper corners of the windshield. Install grommets (item 5) in the upper hole of each set.
- Mount work lamps (item 1) in the bottom holes. Place a .375 flat washer (item 2) between the cab and mounting strap on work lamp and secure with .312 x 1 carriage bolt and .312 whiz nut (items 3 & 4).
- Thread wires from work lamps through grommets into cab. Wires will connect to wires installed in cab.
- Connect the red wire from the right work lamp to the yellow butt connector on the double black wire. Connect the white wire to the yellow butt connector on the double green w/yellow wire. Crimp butt connectors.
- Connect the red wire from the left work lamp to the blue butt connector on the black wire. Connect the white wire to the blue butt connector on the green w/yellow wire. Crimp butt connectors.
- Locate the third set of two holes in the upper right rear corner of cab. Install grommet (item 5) in lower hole.
- Mount third work lamp in the upper hole. Place a .375 flat washer (item 2) between the cab and mounting strap on work lamp and secure with .312 x 1 carriage bolt and .312 whiz nut (items 3 & 4).
- Thread wires from work lamp through grommet inside cab. Wire will connect to wires installed in cab.
- Connect the red wire from work lamp to the blue butt connector on the black wire. Connect the white to the blue butt connector on the green w/yellow wire. Crimp butt connectors.
- Red wires from work lamps should run to switch box. White wires should run to ground.
- Install 7.5 amp fuse (included in kit) in fuse slot marked LIGHTS, located in the Enclosure switch box.

