

INSTRUCTIONS & INFORMATION



HALOGEN LIGHT KIT - ENCLOSURE

Part Number 503340

Use on front mount Grasshopper models with 10.5 Model Enclosure

NOTE: Rear light is not included with this kit. If rear light is desired, order part number 182264 and grommet part number 424229 in addition to this kit. Install following same procedure below.

INSTALLATION INSTRUCTIONS:

(refer to illustration)

- Place unit on a flat level surface.
- Disengage PTO and stop engine.
- Set park brake and remove key from ignition.
- Locate the two sets of two holes near the upper corners of the windshield. Install grommets (item 2) in the upper hole of each set.
- Check work lamp wire lengths. Wires should be trimmed to 8 inches in length. Strip .5" of wire insulation off each wire.
- Mount work lamps (item 1) in the bottom holes. Secure with carriage bolt, lock washer and nut provided.
- Thread wires from work lamps through grommets into cab. Wires will connect to butt connectors in the wiring harness already installed in the top of the cab.

- Connect the red wire from the right work lamp to the yellow butt connector on the double black wire. Connect the black wire to the yellow butt connector on the double green w/yellow wire. Crimp butt connectors.
- Connect the red wire from the left work lamp to the blue butt connector on the black wire. Connect the black wire to the blue butt connector on the green w/yellow wire. Crimp butt connectors.
- Red wires from work lamps should run to switch box. Black wires should run to ground.
- Install 7.5 amp fuse (included in kit) in fuse block marked LIGHTS located in switch box.

