

INSTRUCTIONS & INFORMATION



WIDE SEAT CONVERSION KIT – FOLD UP ARMREST

Part Number 503928

Used on M1, 700 & 900 Series Grasshoppers with Serial Numbers 6000000 and above.

Used on 200VG4 & 500V Series Grasshoppers.

Used on 100V & 200V Series Grasshoppers with Cordura Seats.

INSTALLATION INSTRUCTIONS:

(Refer to illustrations)

- Place unit on a hard level surface.
- Disengage PTO and stop engine.
- Set park brake and remove key from ignition.
- Remove arm rest cushions from seat side assemblies. These will be reinstalled on new wide seat sides with existing bolts.
- Remove seat belt from seat sides. Notice the position of nylon washers when seat belt is removed, as it will be reinstalled on new wide seat sides.
- Tilt seat up and remove bolts securing seat sides and back cushion.

NOTE: To install kit on units with serial number 5999999 and below, also order Seat Reinforcement (order #722884) and replace existing seat reinforcement.

