

# PowerFold®




## Part No. 163161

3348PF  
3452PF  
3452RPF  
3461PF  
3461RPF  
3472LS  
3472LSR  
3472PF  
3552  
3561  
3572  
3661  
3761  
524V/42 PF Deck  
526V/52 Deck

Actuator must be against stops  
when deck is in the down  
position. Failure to support  
actuator may cause rod to bend.  
162173


## Part No. 162173

3348PF  
3452PF  
3452RPF  
3461PF  
3461RPF  
3472LS  
3472LSR  
3472PF  
3552  
3561  
3572  
3661  
3761  
524V/42 PF Deck  
526V/52 Deck



## Part No. 165430

3348PF  
3452PF  
3452RPF  
3461PF  
3461RPF  
3472LS  
3472LSR  
3472PF  
3552  
3561  
3572  
3661  
3761  
524V/42 PF Deck  
526V/52 Deck



## Part No. 162205

(No Step - Actuator)

3472LS  
3472PF  
3472LSR  
3572  
3661  
3761  
524V/42 PF Deck