

INSTRUCTIONS & INFORMATION



GRAMMER SEAT KIT

Part Number 503672

Used on 300G4 models.

Install part #503671 Seat Assembly (not included with this kit) to complete installation.

SEAT REMOVAL INSTRUCTIONS:

- Place unit on a hard level surface.
- Disengage PTO and stop engine.
- Set park brake and remove key from ignition.
- Flip seat up and disconnect seat safety switch wires.
- Remove the seat hinge pins and remove seat. Save the pins, whiz bolts and nuts for later use.

GRAMMER SEAT INSTALLATION INSTRUCTIONS:

(Refer to illustration on page 2)

- Install rubber bumpers (item 14), with two spacers (item 15) beneath, in seat spring holes and secure .312-18 whiz nuts (item 3).
- Set the seat mount assembly (item 1) in place, install the seat hinge pins and secure pins with .312-18 whiz bolts and nuts removed earlier.
- Bolt the seat cable assembly (item 16) to the seat support cross member with .25-20 x .75 whiz bolt, .25 flat washer and .25-20 nylon insert nut (items 17-19).
- Bolt the Grammer seat to the seat mount assembly using four .312-18 x .5 bolts and whiz nuts (items 2 & 3).
- Connect the seat safety switch wires from the tractor to the wiring adapter (item 4) and secure them in the snap clips.
- Make sure the seat latch operates correctly.
- Be sure seat safety switch operates properly. The engine should die if the operator gets off the seat with either steering lever in or the PTO switch on.