





SWITCH BOX



06095

WHEN REMOVING DOZER BLADE FROM TRACTOR, DISCONNECT WIRING HARNESS AT THIS POINT

TO UNIVERSAL WIRING HARNESS



2 WAY FEMALE CONNECTOR TO HYDRAULIC PUMP MOTOR