


CAUTION

Hi Temp Cutoff will not function if coolant level falls below the temperature sender. Cooling system must be maintained at proper coolant level for the sender to function properly.



Item No.	Order No.	Description
604033, 604034		Wiring Assembly Hi Temp Clutch Cutout
1	183935	Push Button Switch
2	833519	Switchbox with Cover
3	184266	Relay