

INSTRUCTIONS & INFORMATION



RELAY BOX/JOYSTICK WIRING ASSEMBLY KIT

Kit Number 504800 (605985)

Use on Grasshopper Front Mount Tractors

NOTE: A 6-way Weather Pack accessory outlet is built into the Joystick wiring harness for the connection of one accessory. Additional accessories may be connected by using a "Y" Adapter (Part #605858).

INSTALLATION INSTRUCTIONS:

(Refer to wiring diagram and illustration on page 2)

- Place unit on a hard level surface.
- Disengage PTO and stop engine.
- Set park brake and remove key from ignition.
- Attach the relay box (item 2) to the seat's right side panel, utilizing the magnet fastened to relay box cover (item 7).
- Raise the seat and connect the 6-way female connector (item 6) to the universal wiring harness. Route wiring between fender and seat and use ties to secure loom in such a manner to remain clear of any moving parts.
- Install the joystick mount (item 13) over the right steering lever's foam grip with the joystick box (item 15) in a "down" position and tighten set screws (item 14). Secure the wiring loom (item 17) to the steering lever with ties provided.
- Connect the 4-way male connector (item 5) from relay box to the 4-way female connector on the attachment wiring harness.
- When removing attachment from tractor, disconnect wiring harness at the 4-way connector.