



Item No.	Order No.	Description
1	183945	Joystick
2	833530	Relay Box – Three Cable
3	184274	Relay – Heavy Duty
4	184272	Relay
5	184977	4 Way Connector - Male
6	184969	6 Way Connector – Female
7	833523	Cover – Magnetic Mt. Relay Box
8	102505	Magnet – Round Base
9	243017	Bolt .25-20 x .625
10	253440	Nut .25-20 Nylon Insert
11	424216	Grommet .5 x .75 x .093
12	424229	Grommet .360 x .630 x .063
13	645567	Mount – Joystick
14	259290	Set Screw 8-32 x .375
15	833514	Switch Box – Joystick
16	833526	Cover – Joystick Box
17	422272	Loom – Flex Guard .25 (Bulk)
18	422275	Loom – Flex Guard .406 (Bulk)
	423147	Tie .125 x 5.5
19	184968	6 Way Connector - Male
20	257020	Washer .25
21	257024	Fender Washer .25

