
MAIN FUSE
15 AMP.
UNIV. PLUG FUSE
10 AMP.
START FUSE
30 AMP.
MASTER FUSE
30 AMP.
IGNITION FUSE
7.5 AMP.
PTO FUSE
10 AMP.
ENGINE
SEE NEXT PAGE
16007