
YELLOW
GREEN
7
LT STRG
10
9
4
BLACK
10
9
6
RT STRG
GREEN
BLACK
BLACK
YELLOW
GREEN
YELLOW
BROWN
BROWN
5
13
SEE NEXT PAGE
BROWN
SEE NEXT PAGE
BROWN
SEE NEXT PAGE
17
1 7 13 19
6 12 18 24
S LI
M
B G
1
2
BRAKE
3
OIL
BLACK
BROWN
BROWN
RED / WHITE
BROWN
BROWN
YELLOW
WHITE
GREEN
19
13
A
21
21
21
GREEN
BLUE
YELLOW
YELLOW
RED
RED
GREEN
8
SEAT
20
NC
NO
WHITE
YELLOW/BROWN
GREEN
PURPLE
BLACK
GREEN
YELLOW
RED
BLUE
BLACK
16
15
14
+
GREEN/YELLOW
BLUE
13
B
12
START FUSE
30 AMP.
17
18
30
10
30
7.5
10
UNIVERSAL
HARNESS FUSE
10 AMP.
PTO FUSE
10 AMP.
MASTER FUSE
30 AMP.
IGN./FUEL FUSE
7.5 AMP.
BLUE
STARTER
REG.
OIL
MAG.
SOLENOID
GROUND
TO
ENGINE
CLUTCH
11
GREEN
16065A