
IGNITION FUSE
7.5 AMP.
PTO FUSE
10 AMP.
MAIN FUSE
15 AMP.
ACCESSORY FUSES
START FUSE
30 AMP.
LT STRG
RT STRG
BRAKE
SEAT
OIL
TEMP.
BATTERY
ALT.
STARTER
ENGINE
GLOW PLUG
FUEL SOLENOID
CLUTCH
40 AMP REG. FUSE
NC
NO
GREEN
BROWN
YELLOW
BLACK
WHITE
RED
BLUE
PURPLE
GREEN W/YELLOW
YELLOW W\BROWN
YELLOW W/BROWN
BLACK W/WHITE
RED W/WHITE
06063A