
LT STRG
RT STRG
YELLOW
GREEN
BROWN
BLACK
BLUE
RED W/WHITE
RED
GREEN W/YELLOW
YELLOW W/BROWN
BLACK W/WHITE
WHITE
PURPLE
BRAKE
SEAT
OIL
TEMP.
BATTERY
ALT.
TEMP
GLOW PLUG
ENGINE
CLUTCH
STARTER
FUEL SOLENOID
COMM
PULL
HOLD
SOLENOID FUSE
7.5 AMP.
PTO FUSE
10 AMP.
MAIN FUSE
15 AMP.
REGULATOR FUSE
30 AMP.
ACCESSORY FUSES
START FUSE
30 AMP.
06055A