

INSTRUCTIONS & INFORMATION



FOOTREST RISER

Part Number 533275

Used on 300G4&G5 Models

This Kit has been designed to provide a higher platform on the footrest.

INSTALLATION INSTRUCTIONS:

(Refer to illustration)

1. The four Modified Isolators (item 2) have been installed on the Footrest Riser (item 1) at the factory. A .25" hex head bolt (item 3) has been inserted into the bottom hole of each isolator.
2. Place the Riser over the footrest so that bolts in the isolators can be inserted into the holes in footrest indicated in illustration.
3. Secure Riser to footrest with the .25" SAE washers and .25" nylon insert nuts provided.

Item No.	Order No.	Description
1	724383	Riser - 300V Footrest
2	833660	Isolator - Modified
3	243025	Bolt .25-20 x 1
4	253179	Whiz Bolt .25-20 x .75 Phil. Truss
5	257021	Washer .25 SAE
6	253440	Nut - .25-20 Nylon Insert

