

INSTRUCTIONS & INFORMATION



WIRING ADAPTER - ELECTRIC LIFT

Part Number 604924

Used to adapt 1997 and older electric lift AERA-vator™ to universal tractor harness.

INSTALLATION INSTRUCTIONS

- Install switch box under the right arm rest. Remove front bolt from right arm rest and install stop clip. Do not tighten bolt.
- Remove rear bolt from right arm rest and install switch box mounting bracket. Place narrow end of mounting bracket toward the front. Secure bracket by sliding .312-18 x 1.5 bolt through flat washer, spacer, and spring and into bottom of arm rest.
- Slide the switch box onto the mounting bracket. Adjust stop clip to hold switch box from sliding off bracket. Secure stop clip.
- To remove switch box, force the rear of mounting bracket toward the arm rest and slide off bracket.
- Drill .25" diameter hole in seat bottom panel's side approximately 4.25" ahead of seat latch mount pin. Install nylon wire harness clip and secure wire harness.
- Route harness between seat and control console. Connect the 8 way clear connector to the 8 way black connector in the tractor's universal wiring harness. The 8 way black connector in the wiring adapter harness connects to the 8 way connector in the wiring harness from the AERA-vator™.